

Seiko Australia - Nike Spare Parts Identification Guide (updated 29th June 06)

Model Style Name	Model SKU	Part Description	Part Number	Colour
ACG Ascent Compass	WA0007	Band	L-WA0007001B	Black/Green
ACG Ascent Compass	WA0007	Band	L-WA0007003B	Black/Light Brown
ACG Ascent Compass	WA0007	Band	L-WA0007401B	Navy Blue/Black
ACG Ascent Compass	WA0007	Band	L-WA0007402B	Light Grey/Fluoro Yellow
ACG Ascent Compass	WA0007	Movement/Case	L-WA0007003MV	Black/Light Brown (complete watch head)
ACG Ascent Compass	WA0007	Back Gasket	L-0F322BZ11	
ACG Field Regular	WA0005	Band	L-WA0005001B	Black
ACG Field Regular	WA0005	Case	L-WA0005001CA	Black/Silver
Agent Regular	WX0017	Band	L-WX0017001B	Black
Agent Regular	WX0017	Movement	L-WX0017MV	
Agent Regular	WX0017	Back Gasket	L-0F260BAA1	
Agent Super	WX0018	Band	L-WX0018001B	Black
Agent Super	WX0018	Movement	L-WX0018MV	
Agent Super	WX0018	Back Gasket	L-0F290BAA3	
Ambalog Regular	WA0012	Band	L-WA0012001B	Black/Soft Grey
Ambalog Regular	WA0012	Band	L-WA0012301B	Dark Olive/Soft Grey
Ambalog Regular	WA0012	Band	L-WA0012401B	Light Blue/Soft Grey
Ambalog Regular	WA0012	Band	L-WA0012701B	Yellow/Soft Grey
Ambalog Regular	WA0012	Movement	L-WA0012MV	
Ambalog Regular	WA0012	Back Gasket	L-FE238BA11	
Ambient Frozen Regular	WA0001	Band	L-WA0001001B	Black/Grey
Ambient Frozen Regular	WA0001	Band	L-WA0001009B	Olive/Dark Green
Ambient Frozen Regular	WA0001	Band	L-WA0001501B	Dark Purple/Light Purple
Ambient Frozen Regular	WA0001	Case	L-WA0001001CA	
Ambient Frozen Regular	WA0001	Movement	L-WA0001MV	
Ambient Frozen Regular	WA0001	Back Gasket	L-WA0001BS	
Note: See also Ambient Fresh (WA0002) for subs				
Ambient Fresh	WA0002	Band (material)	L-WA0002203B	Black stretchy material
Note: See also Ambient Frozen (WA0001) for subs				
Ambient Frozen Super	WA0009	Band	L-WA0009001B	Black/Grey
Ambient Frozen Super	WA0009	Band	L-WA0009003B	Navy/Black
Ambient Frozen Super	WA0009	Band	L-WA0009401B	Blue/Grey
Ambient Frozen Super	WA0009	Case	L-WA0009001CA	
Ambient Frozen Super	WA0009	Movement	L-WA0009MV	
Ambient Frozen Super	WA0009	Back Gasket	L-WA0009BS	
Anvil Regular	WC0019	Band	L-WC0019001B	Black
Anvil Regular	WC0019	Band	L-WC0019401B	Blue
Anvil Regular	WC0019	Case	L-WC0019001CA	Silver case with Green EL Button
Anvil Regular	WC0019	Case	L-WC0019401CA	Silver case with Yellow EL Button
Anvil Regular	WC0019	Movement	L-WC0019MV	Silver display
Anvil Regular	WC0019	Movement	L-WC0019MVB	Black display (reverse LCD)
Anvil Regular	WC0019	Back Gasket	L-WC0019BS	
Anvil Regular	WC0019	3 button set	L-WC0019BSET	Silver
Anvil Regular	WC0019	EL button	L-WC0019001ELB	Green EL button
Anvil Regular	WC0019	EL button	L-WC0019401ELB	Yellow EL button
Anvil Regular	WC0019	Band screws	L-WC0019BSCW	Screws to attach band to case
Anvil Regular Co-Mold	WR0100	Band	L-WR0100017B	Green/Black
Anvil Regular Co-Mold	WR0100	Case	L-WR0100017CA	Silver case with black buttons
Anvil Regular Co-Mold	WR0100	Movement	L-WC0019MVB	Black display (reverse LCD)
Anvil Regular Co-Mold	WR0100	Back Gasket	L-WC0019BS	
Anvil Regular Co-Mold	WR0100	Band screws	L-WC0019BSCW	Screws to attach band to case
Aruba Regular	WW0010	Case/Band	L-WW0010001CB	Dark Chocolate
Aruba Regular	WW0010	Case/Band	L-WW0010002CB	Creamy Grey - DISCONTINUED
Aruba Regular	WW0010	Case/Band	L-WW0010501CB	Dark Purple
Aruba Regular	WW0010	Movement	L-WW0010MV	
Aruba Regular	WW0010	Back Gasket	L-WW0010BS	
Aruba Regular	WW0010	Dial	L-WW0010001DL	Black dial
Aruba Regular	WW0010	Crown	L-WW0010CN	
Aruba Super	WW0005	Case/Band	L-WW0005001CB	Dark Chocolate
Aruba Super	WW0005	Case/Band	L-WW0005002CB	Neutral Grey
Aruba Super	WW0005	Case/Band	L-WW0005401CB	Midnight Navy
Aruba Super	WW0005	Movement	L-WW0005MV	
Aruba Super	WW0005	Back Gasket	L-WW0005BS	
Aruba Super	WW0005	Crown	L-WW0005CN	
Ballistic 15 Regular	WR0026	Band	L-WR0026001B	Black
Ballistic 15 Regular	WR0026	Band	L-WR0026007B	Dark Chocolate
Ballistic 15 Regular	WR0026	Band	L-WR0026404B	Bright Blue
Ballistic 15 Regular	WR0026	Band	L-WR0026405B	Dark Blue
Ballistic 15 Regular	WR0026	Band	L-WR0026407B	Light Blue
Ballistic 15 Regular	WR0026	Movement/Case	L-WR0026001MV	Black (complete watch head)
Ballistic 15 Regular	WR0026	Movement/Case	L-WR0026002MV	Silver (complete watch head)
Ballistic 15 Regular	WR0026	Back Gasket	L-WR0026BS	

Seiko Australia - Nike Spare Parts Identification Guide (updated 29th June 06)

Model Style Name	Model SKU	Part Description	Part Number	Colour
Ballistic 15 Super	WR0021	Band	L-WR0021001B	Black
Ballistic 15 Super	WR0021	Band	L-WR0021002B	Grey
Ballistic 15 Super	WR0021	Case	L-WR0021002CA	Silver
Ballistic 15 Super	WR0021	Movement	L-WR0021MV	
Ballistic 15 Super	WR0021	Back Gasket	L-WR0021BS	
Ballistic 26 Regular	WR0025	Band	L-WR0025001B	Black/Dark Grey
Ballistic 26 Regular	WR0025	Band	L-WR0025003B	Dark Grey/Light Grey
Ballistic 26 Regular	WR0025	Movement/Case	L-WR0025001MV	Black (complete watch head)
Ballistic 26 Regular	WR0025	Back Gasket	L-WR0033BS	Sub gasket
Ballistic 26 Super	WR0022	Band	L-WR0022001B	Black/Light Grey
Ballistic 26 Super	WR0022	Band	L-WR0022003B	Dark Grey/Light Grey
Ballistic 26 Super	WR0022	Band	L-WR0022004B	Dark Blue/Red
Ballistic 26 Super	WR0022	Band	L-WR0022006B	Black/Dark Grey
Ballistic 26 Super	WR0022	Band	L-WR0022401B	Dark Blue/Black
Ballistic 26 Super	WR0022	Case	L-WR0022001CA	Black with light grey trim
Ballistic 26 Super	WR0022	Movement	L-WR0022MV	
Ballistic 26 Super	WR0022	Back Gasket	L-WR0022BS	
BIG AL	WC0001	Band	L-WC0001001B	Stainless Steel
BIG AL	WC0001	Movement/Case	L-WC0001001MV	Stainless Steel (complete watch head)
BIG AL	WC0001	Push pin	L-WC0001PP	
BIG AL	WC0001	Batt hatch seal	L-WC0001BHS	
BIG AL Analog	WC0008	Band	L-WC0001001B	Stainless Steel
BIG AL Analog	WC0008	Movement/Case	L-WC0008001MV	Black/Green dial (complete watch head)
BIG AL Analog	WC0008	Push pin	L-WC0001PP	
BIG AL Analog	WC0008	Batt hatch seal	L-WC0008BHS	
Cayman Super	WW0006	Case/Band	L-WW0006001CB	Black
Covert	WX0016	Band	L-WX0016002B	Black/Light Grey
Covert	WX0016	Band	L-WX0016004B	Black/Grey
Covert	WX0016	Band	L-WX0016009B	Black/Dark Grey
Covert	WX0016	Movement	L-WX0015MV	
Covert	WX0016	Back Gasket	L-WX0015BS	
Note: See also Reveal (WX0015) for sub bands				
Cuff	WR0094	Band	L-WR0094902B1	Black (black logo on tag)
Cuff	WR0094	Band	L-WR0094902B2	Half Black & half Red with Grey stripe dividing
Cuff	WR0094	Band	L-WR0094902B3	Red with 2 White & 2 Black stripes
Cuff	WR0094	Band	L-WR0094910B1	White (grey logo on tag)
Cuff	WR0094	Band	L-WR0094910B2	Blue with single White stripe
Cuff	WR0094	Band	L-WR0094910B3	White with 2 Grey & 2 Blue stripes
Cuff	WR0094	Band	L-WR0094914B1	Grey with 4 Pink curved stripes
Cuff	WR0094	Band	L-WR0094914B2	Pink with 3 Dark Grey & 2 Grey stripes
Cuff	WR0094	Band	L-WR0094914B3	Dark Grey (Pink logo on tag)
Cuff	WR0094	Band	L-WR0094916B1	Purple with 4 Orange curved stripes
Cuff	WR0094	Band	L-WR0094916B2	Light Blue with 3 Purple & 2 Orange stripes
Cuff	WR0094	Band	L-WR0094916B3	Orange (light blue logo on tag)
Cuff	WR0094	Movement/Case	L-WR0094MV	Black (complete watch head - black display)
Cuff	WR0094	Back Gasket	L-WR0094BS	
Flathead	WX0001	Band	L-WX0001001B	Black
Flathead	WX0001	Movement	L-WX0001MV	Duo movement (reverse LCD)
Flathead	WX0001	Back Gasket	L-0F286BEA1	
Note: May also come in Model Reference WX0002, WX0003, WX0007, WX0008, WX0009 & WX0012				
Note: Steelhead bands DO NOT fit Flathead watches				
Gorge	WK0010	Case/Band	L-WK0010001CB	Black with Black bezel
Gorge	WK0010	Case/Band	L-WK0010023CB	Black with Silver bezel
Gorge	WK0010	Case/Band	L-WK0010415CB	Blue with Silver bezel
Gorge	WK0010	Movement	L-WK0010MV	Silver display
Gorge	WK0010	Movement	L-WK0010MVB	Black display (reverse LCD)
Gorge	WK0010	Movement	L-WK0010MVRED	Red display
Gorge	WK0010	Movement	L-WK0010MVGRN	Green display
Gorge	WK0010	Back Gasket	L-WK0009BS	
Hammer	WC0021	Band	L-WC0021001B	Black
Hammer	WC0021	Band	L-WC0021701B	Yellow
Hammer	WC0021	Band	L-WC0021805B	Orange
Hammer	WC0021	Case	L-WC0021001CA	Silver case with Green EL button
Hammer	WC0021	Case	L-WC0021701CA	Silver case with Black EL button
Hammer	WC0021	Case	L-WC0021805CA	Silver case with Orange EL button
Hammer	WC0021	Movement	L-WC0021MVB	Black display (reverse LCD)
Hammer	WC0021	Back Gasket	L-WC0021BS	
Hammer	WC0021	3 button set	L-WC0021BSET	Silver
Hammer	WC0021	EL button	L-WC0021001ELB	Green EL button
Hammer	WC0021	EL button	L-WC0021701ELB	Black EL button
Hammer	WC0021	Band screws	L-WC0021BSCW	Screws to attach band to case

Seiko Australia - Nike Spare Parts Identification Guide (updated 29th June 06)

Model Style Name	Model SKU	Part Description	Part Number	Colour
HRM Triax 15	SM0002	Band	L-SM0002002B	Black - DISCONTINUED
HRM Triax 15	SM0002	Case	L-SM0002002CA	Black with black bezel
HRM Triax 15	SM0002	Movement	L-SM0002MV	
HRM Triax 15	SM0002	Back Gasket	L-SM0001BS	
HRM Triax 15	SM0002	Batt hatch seal	L-SM0001BHS	
HRM Triax 15	SM0002	Chest strap seal	L-SM0013CSS	
HRM Triax 15	SM0002	Chest strap	L-SM0013219SEN	Dark Grey sensor unit & black strap
<i>Note: See also HRM Triax 100 (SM0001), HRM Triax Inspire (SM0008) & SDM Triax 100 (SM0003) for sub bands</i>				
HRM Triax 100	SM0001	Band	L-SM0001001B	Black - DISCONTINUED
HRM Triax 100	SM0001	Band	L-SM0001402B	Dark Blue with black trim
HRM Triax 100	SM0001	Case	L-SM0001001CA	Black with light blue trim & silver bezel
HRM Triax 100	SM0001	Case	L-SM0001003CA	Black with light blue trim & black bezel
HRM Triax 100	SM0001	Case	L-SM0001402CA	Silver with black trim & silver bezel
HRM Triax 100	SM0001	Movement	L-SM0001MV	
HRM Triax 100	SM0001	Back Gasket	L-SM0001BS	
HRM Triax 100	SM0001	Batt hatch seal	L-SM0001BHS	
HRM Triax 100	SM0001	Chest strap seal	L-SM0013CSS	
HRM Triax 100	SM0001	Chest strap	L-SM0013219SEN	Dark Grey sensor unit & black strap
<i>Note: See also HRM Triax 15 (SM0002), HRM Triax Inspire (SM0008) & SDM Triax 100 (SM0003) for sub bands</i>				
HRM Triax C3	SM0013	Case/Band	L-SM0013001CB	Black
HRM Triax C3	SM0013	Movement	L-SM0013MV	
HRM Triax C3	SM0013	Back Gasket	L-SM0013BS	
HRM Triax C3	SM0013	Chest strap seal	L-SM0013CSS	
HRM Triax C3	SM0013	Chest strap	L-SM0013219SEN	Dark Grey sensor unit & black strap
HRM Triax C5	SM0015	Case/Band	L-SM0015001CB	Black
HRM Triax C5	SM0015	Movement	L-SM0015MV	
HRM Triax C5	SM0015	Back Gasket	L-SM0014BS	
HRM Triax C5	SM0015	Batt hatch seal	L-SM0013BHS	
HRM Triax C5	SM0015	Chest strap seal	L-SM0013CSS	
HRM Triax C5	SM0015	Chest strap	L-SM0013219SEN	Dark Grey sensor unit & black strap
HRM Triax C6	SM0014	Case/Band	L-SM0014001CB	Black/Light blue
HRM Triax C6	SM0014	Movement	L-SM0014MV	
HRM Triax C6	SM0014	Back Gasket	L-SM0014BS	
HRM Triax C6	SM0014	Batt hatch seal	L-SM0013BHS	
HRM Triax C6	SM0014	Chest strap seal	L-SM0013CSS	
HRM Triax C6	SM0014	Chest strap	L-SM0013219SEN	Dark Grey sensor unit & black strap
HRM Triax C8	SM0017	Case/Band	L-SM0017001CB	Black/Grey
HRM Triax C8	SM0017	Movement	L-SM0017MV	
HRM Triax C8	SM0017	Back Gasket	L-SM0017BS	
HRM Triax C8	SM0017	Batt hatch seal	L-SM0013BHS	
HRM Triax C8	SM0017	Chest strap seal	L-SM0013CSS	
HRM Triax C8	SM0017	Chest strap	L-SM0013219SEN	Dark Grey sensor unit & black strap
HRM Triax C10	SM0016	Case/Band	L-SM0016001CB	Black/Grey
HRM Triax C10	SM0016	Movement	L-SM0016MV	
HRM Triax C10	SM0016	Back Gasket	L-SM0017BS	
HRM Triax C10	SM0016	Batt hatch seal	L-SM0013BHS	
HRM Triax C10	SM0016	Chest strap seal	L-SM0013CSS	
HRM Triax C10	SM0016	Chest strap	L-SM0016001SEN	Dark Grey sensor unit & black strap
HRM/SDM Triax CV10	SM0020	Case/Band	L-SM0020001CB	Black/Grey
HRM/SDM Triax CV10	SM0020	Movement	L-SM0020MV	
HRM/SDM Triax CV10	SM0020	Back Gasket	L-SM0017BS	
HRM/SDM Triax CV10	SM0020	Batt hatch seal	L-SM0013BHS	
HRM/SDM Triax CV10	SM0020	Chest strap seal	L-SM0013CSS	
HRM/SDM Triax CV10	SM0020	Chest strap	L-SM0016001SEN	Dark Grey sensor unit & black strap
HRM/SDM & HRM Triax Elite	SM0019/30	Band	L-SM0019001B	Black
HRM/SDM & HRM Triax Elite	SM0019/30	Movement/Case	L-SM0019MV	Black/Grey (complete watch head)
HRM/SDM & HRM Triax Elite	SM0019/30	Batt hatch seal	L-SM0019BHS	
HRM/SDM & HRM Triax Elite	SM0019/30	Chest strap seal	L-SM0013CSS	
HRM/SDM & HRM Triax Elite	SM0019/30	Chest strap	L-SM0019001SEN	Dark Grey sensor unit & black strap
HRM Triax Inspire	SM0008	Band	L-SM0008001B	Black - DISCONTINUED
HRM Triax Inspire	SM0008	Case	L-SM0008001CA	Black with grey bezel
HRM Triax Inspire	SM0008	Movement	L-SM0008MV	
HRM Triax Inspire	SM0008	Back Gasket	L-SM0001BS	
HRM Triax Inspire	SM0008	Batt hatch seal	L-SM0001BHS	
HRM Triax Inspire	SM0008	Chest strap seal	L-SM0013CSS	
HRM Triax Inspire	SM0008	Chest strap	L-SM0013219SEN	Dark Grey sensor unit & black strap
<i>Note: See also HRM Triax 15 (SM0002), HRM Triax 100 (SM0001) & SDM Triax 100 (SM0003) for sub bands</i>				
Hurricane	WW0004	Case/Band	L-WW0004001CB	Translucent Grey - DISCONTINUED
Hurricane	WW0004	Case/Band	L-WW0004401CB	Translucent Aqua Blue
Hurricane	WW0004	Case/Band	L-WW0004404CB	Translucent Bright Blue
Hurricane	WW0004	Case/Band	L-WW0004601CB	Translucent Red
Hurricane	WW0004	Movement	L-WW0004MV	Movement without date
Hurricane	WW0004	Movement	L-WW0004MVD	Movement with date at 6 o'clock
Hurricane	WW0004	Back Gasket	L-OF262BZ11	
Huru	WK0011	Case/Band	L-WK0011417CB	Light Blue (Green on underside)
Huru	WK0011	Case/Band	L-WK0011614CB	Red (Purple on underside)

Seiko Australia - Nike Spare Parts Identification Guide (updated 29th June 06)				
Model Style Name	Model SKU	Part Description	Part Number	Colour
Huru	WK0011	Movement	L-WR0033MV	
Huru	WK0011	Back Gasket	L-WK0011BS	

Seiko Australia - Nike Spare Parts Identification Guide (updated 29th June 06)

Model Style Name	Model SKU	Part Description	Part Number	Colour
Imara Fit	WR0076	Band	L-WR0076001B	Black
Imara Fit	WR0076	Band	L-WR0076002B	Light Blue
Imara Fit	WR0076	Band	L-WR0076410B	Dark Blue
Imara Fit	WR0076	Band	L-WR0076501B	Purple
Imara Fit	WR0076	Movement/Case	L-WR0076001MV	Black case & Silver bezel (complete watch head)
Imara Fit	WR0076	Movement/Case	L-WR0076002MV	Light Blue case & Silver bezel (complete watch head)
Imara Fit	WR0076	Movement/Case	L-WR0076410MV	Dark Blue case & Silver bezel (complete watch head)
Imara Fit	WR0076	Movement/Case	L-WR0076501MV	Purple case & purple bezel (complete watch head)
Imara Fit	WR0076	Band Fixing Pin	L-WR0075PIN	
Imara Fit	WR0076	Batt Hatch Seal	L-WR0075BHS	
Imara HRM	SM0032	Band	L-SM0032001B	Black
Imara HRM	SM0032	Band	L-SM0032002B	Light Blue
Imara HRM	SM0032	Band	L-SM0032608B	Pink
Imara HRM	SM0032	Movement/Case	L-SM0032MV	Silver (complete watch head)
Imara HRM	SM0032	Band Fixing Pin	L-WR0075PIN	
Imara HRM	SM0032	Batt Hatch Seal	L-SM0032BHS	
Imara HRM	SM0032	Chest strap seal	L-SM0013CSS	
Imara HRM	SM0032	Chest Strap	L-SM0032001SEN	Black sensor unit & black strap
Imara HRM	SM0032	Chest Strap	L-SM0032002SEN	Light Blue sensor unit & black strap
Imara HRM	SM0032	Chest Strap	L-SM0032608SEN	Pink sensor unit & black strap
Imara Run	WR0075	Band	L-WR0075005B	Black (gold buckle)
Imara Run	WR0075	Band	L-WR0075199B	White
Imara Run	WR0075	Band	L-WR0075410B	Dark Blue
Imara Run	WR0075	Band	L-WR0075414B	Pale Blue
Imara Run	WR0075	Band	L-WR0075601B	Pink
Imara Run	WR0075	Movement/Case	L-WR0075005MV	Gold bezel & black display (complete watch head)
Imara Run	WR0075	Movement/Case	L-WR0075199MV	High polish bezel & white glass (complete watch head)
Imara Run	WR0075	Movement/Case	L-WR0075410MV	Brushed bezel & grey glass (complete watch head)
Imara Run	WR0075	Movement/Case	L-WR0075414MV	High polish bezel & grey glass (complete watch head)
Imara Run	WR0075	Movement/Case	L-WR0075601MV	High polish bezel & grey glass (complete watch head)
Imara Run	WR0075	Band Fixing Pin	L-WR0075PIN	
Imara Run	WR0075	Batt Hatch Seal	L-WR0075BHS	
Lance Chrono	WA0039	Band	L-WA0039001B	Titanium & Black Rubber
Lance Chrono	WA0039	Case	L-WA0039001CA	Titanium
Lance Chrono	WA0039	Movement	L-WA0039MV	
Lance Chrono	WA0039	Back Gasket	L-WA0039BS	
Lance Tour Pack (sold as WA0041-001)	WA0044	Band	L-WA0044013B	Black
Lance Tour Pack (sold as WA0041-001)	WA0044	Case	L-WA0044013CA	Titanium
Lance Tour Pack (sold as WA0041-001)	WA0044	Movement	L-WA0039MV	
Lance Tour Pack (sold as WA0041-001)	WA0044	Back Gasket	L-WA0039BS	
Lance 4	WA0020	Band	L-WA0020013B	Black
Lance 4	WA0020	Movement/Case	L-WA0020MV	Titanium/Black (complete watch head)
Lance 4	WA0020	Back Gasket	L-WA0018BS	
Lance 4	WA0020	Batt hatch seal	L-WA0018BHS	
Merge Attract	WC0024	Band	L-WC0024003B	Black (dark pink on underside)
Merge Attract	WC0024	Band	L-WC0024103B	Off-White (Light Green on underside)
Merge Attract	WC0024	Case	L-WC0024003CA	Black sides
Merge Attract	WC0024	Case	L-WC0024103CA	Off-White sides
Merge Attract	WC0024	Movement	L-WR0033MV	
Merge Attract	WC0024	Back Gasket	L-WC0024BS	
Merge Attract	WC0024	Push Pin	L-WC0024PP	
Merge Lift	WC0026	Band	L-WC0026216B	Off-White (Light Green on underside)
Merge Lift	WC0026	Case	L-WC0026216CA	Grey sides
Merge Lift	WC0026	Movement	L-WC0026MV	Silver display
Merge Lift	WC0026	Movement	L-WC0026MVB	Black display (reverse LCD)
Merge Lift	WC0026	Back Gasket	L-WC0026BS	
Merge Lift	WC0026	Push Pin	L-WC0026PP	
Merge Step	WC0025	Band	L-WC0025415B	Light Blue (Grey on underside)
Merge Step	WC0025	Case	L-WC0025415CA	Grey sides
Merge Step	WC0025	Movement	L-WC0025MV	Silver display
Merge Step	WC0025	Movement	L-WC0025MVB	Black display (reverse LCD)
Merge Step	WC0025	Back Gasket	L-WC0025BS	
Merge Step	WC0025	Push Pin	L-WC0025PP	
Merge Transit	WC0033	Band	L-WC0033903B	Light Gold (Dark Grey on underside)
Merge Transit	WC0033	Case	L-WC0033903CA	Grey sides
Merge Transit	WC0033	Movement	L-WC0025MV	Silver display
Merge Transit	WC0033	Movement	L-WC0025MVB	Black display (reverse LCD)
Merge Transit	WC0033	Back Gasket	L-WC0025BS	
Merge Transit	WC0033	Push Pin	L-WC0025PP	
Nuru	WK0012	Case/Band	L-WK0012024CB	Black (Pink on underside)
Nuru	WK0012	Case/Band	L-WK0012501CB	Purple (Light Blue on underside)
Nuru	WK0012	Case/Band	L-WK0012613CB	Pink (Purple on underside)
Nuru	WK0012	Movement	L-WK0012MV	
Nuru	WK0012	Back Gasket	L-WK0012BS	

Seiko Australia - Nike Spare Parts Identification Guide (updated 29th June 06)

Model Style Name	Model SKU	Part Description	Part Number	Colour
Oregon Series Alt-Compass	WA0018	Band	L-WA0018001B	Black
Oregon Series Alt-Compass	WA0018	Movement/Case	L-WA0018MV	Silver/Black (complete watch head)
Oregon Series Alt-Compass	WA0018	Back Gasket	L-WA0018BS	
Oregon Series Alt-Compass	WA0018	Batt hatch seal	L-WA0018BHS	
Note: Band and gaskets also suit Oregon Series Alt (WA0019)				
Oregon Alt-Race	WA0027	Band	L-WA0027001B	Black
Oregon Alt-Race	WA0027	Movement/Case	L-WA0027MV	Black (complete watch head)
Oregon Alt-Race	WA0027	Batt hatch seal	L-WA0018BHS	
Note: Band also suits Lance-Race (WA0040)				
Oregon Series Analog Chrono	WA0022	Band	L-WA00221001B	Black
Oregon Series Analog Chrono	WA0022	Case	L-WA0022CA	Silver/Black
Oregon Series Analog Chrono	WA0022	Movement	L-WA0022MV	
Oregon Series Analog Chrono	WA0022	Back Gasket	L-WA0021BS	
Oregon Series Analog Regular	WA0025	Band	L-WA0025001B	Black
Oregon Series Analog Regular	WA0025	Case	L-WA0025CA	Silver/Black
Oregon Series Analog Regular	WA0025	Movement	L-WA0025MV	
Oregon Series Analog Regular	WA0025	Back Gasket	L-WA0025BS	
Oregon Series Analog Super	WA0021	Band	L-WA0021001B	Black
Oregon Series Analog Super	WA0021	Case	L-WA0021CA	Silver/Black
Oregon Series Analog Super	WA0021	Movement	L-WA0021MV	
Oregon Series Analog Super	WA0021	Back Gasket	L-WA0021BS	
Oregon Series Digital Regular	WA0023	Band	L-WA0023001B	Black
Oregon Series Digital Regular	WA0023	Case	L-WA0023001CA	Black/Silver
Oregon Series Digital Regular	WA0023	Movement	L-WA0023MV	
Oregon Series Digital Regular	WA0023	Back Gasket	L-WA0023BS	
Oregon Series Digital Regular	WA0023	Batt hatch seal	L-WA0023BHS	
Oregon Series Digital Super	WA0024	Band	L-WA0024001B	Black
Oregon Series Digital Super	WA0024	Case	L-WA0024001CA	Black/Silver
Oregon Series Digital Super	WA0024	Movement	L-WA0024MV	
Oregon Series Digital Super	WA0024	Back Gasket	L-WA0024BS	
Oregon Series Digital Super	WA0024	Batt hatch seal	L-WA0024BHS	
Oregon Series Digital Dark Super	WA0034	Band	L-WA0034001B	Black
Oregon Series Digital Dark Super	WA0034	Case	L-WA0034CA	Black
Oregon Series Digital Dark Super	WA0034	Movement	L-WA0034MV	Black display
Oregon Series Digital Dark Super	WA0034	Back Gasket	L-WA0024BS	
Oregon Series Digital Dark Super	WA0034	Batt hatch seal	L-WA0024BHS	
Oregon Series Digital Fabric Super	WA0031	Band	L-WA0031001B	Black
Oregon Series Digital Fabric Super	WA0031	Case	L-WA0031CA	Black/Silver
Oregon Series Digital Fabric Super	WA0031	Movement	L-WA0024MV	
Oregon Series Digital Fabric Super	WA0031	Back Gasket	L-WA0024BS	
Oregon Series Digital Fabric Super	WA0031	Batt hatch seal	L-WA0024BHS	
Oregon Square Digital	WA0036	Band	L-WA0036001B	Black
Oregon Square Digital	WA0037	Band	L-WA0037201B	Olive canvas
Oregon Square Digital	WA0036	Case	L-WA0036CA	Silver
Oregon Square Digital	WA0036	Movement	L-WA0036MV	
Oregon Square Digital	WA0036	Back Gasket	L-WA0036BS	
Oregon Square Digital	WA0036	Batt hatch seal	L-WA0018BHS	
Oregon Square Digital	WA0036	Band pin/screws	L-WA0036BSCV	Pin & screws to attach band to case
Oregon Square Digital	WA0036	Clasp push pin	L-WA0036PP	Push pin to attach clasp to band
Presto - All sizes & styles	All models	Batt hatch seal	L-PRESBHS	
Range	WK0009	Case/Band	L-WK0009020CB	Black with Silver bezel
Range	WK0009	Case/Band	L-WK0009022CB	Black with Red bezel
Range	WK0009	Case/Band	L-WK0009415CB	Blue with Silver bezel
Range	WK0009	Movement	L-WR0033MV	
Range	WK0009	Back Gasket	L-WK0009BS	
Reveal	WX0015	Band	L-WX0015003B	Black/Light Grey
Reveal	WX0015	Band	L-WX0015005B	Midnight Navy/Light Grey
Reveal	WX0015	Band	L-WX0015401B	Black/Teal
Reveal	WX0015	Movement	L-WX0015MV	
Reveal	WX0015	Back Gasket	L-WX0015BS	
Note: See also Covert (WX0016) for sub bands				
Reveal II	WC0005	Band	L-WC0005002B	Black
Reveal II	WC0005	Movement	L-WX0015MV	
Reveal II	WC0005	Back Gasket	L-WX0015BS	
Reveal II (Metal)	WC0006	Band	L-WC0006001B	Black
Reveal II (Metal)	WC0006	Case	L-WC0006001CA	Silver
Reveal II (Metal)	WC0006	Movement	L-WX0015MV	
Reveal II (Metal)	WC0006	Back Gasket	L-WC0006BS	

Seiko Australia - Nike Spare Parts Identification Guide (updated 29th June 06)

Model Style Name	Model SKU	Part Description	Part Number	Colour
RON	WC0002	Band	L-WC0002001B	Stainless Steel
RON	WC0002	Movement/Case	L-WC0002001MV	Stainless Steel (complete watch head)
RON	WC0002	Push pin	L-WC0002PP	
RON	WC0002	Batt hatch seal	L-WC0001BHS	
RON Analog	WC0009	Band	L-WC0009006B	Stainless Steel
RON Analog	WC0009	Movement/Case	L-WC0009006MV	Black/Blue dial (complete watch head)
RON Analog	WC0009	Push pin	L-WC0001PP	
RON Analog	WC0009	Batt hatch seal	L-WC0008BHS	
SDM Triax 100	SM0003	Band	L-SM0003001B	Black - DISCONTINUED
SDM Triax 100	SM0003	Case	L-SM0003001CA	Black
SDM Triax 100	SM0003	Movement	L-SM0003MV	
SDM Triax 100	SM0003	Back Gasket	L-SM0001BS	
SDM Triax 100	SM0003	Batt hatch seal	L-SM0001BHS	
Note: This model does not utilize a chest strap & sensor				
Note: See also HRM Triax 15 (SM0002), HRM Triax 100 (SM0001) & HRM Triax Inspire (SM0008) for sub bands				
STAN	WC0003	Band	L-WC0003001B	Stainless Steel
STAN	WC0003	Movement/Case	L-WC0003001MV	Stainless Steel (complete watch head)
STAN	WC0003	Push pin	L-WC0001PP	
STAN	WC0003	Batt hatch seal	L-WC0001BHS	
STAN Analog	WC0010	Band	L-WC0010007B	Stainless Steel
STAN Analog	WC0010	Movement/case	L-WC0010007MV	Black/Orange dial (complete watch head)
STAN Analog	WC0010	Push pin	L-WC0001PP	
STAN Analog	WC0010	Batt hatch seal	L-WC0008BHS	
Steel Agent Regular	WX0019	Band	L-WX0019002B	Dark Shadow
Steel Agent Regular	WX0019	Movement	L-WX0017MV	
Steel Agent Regular	WX0019	Back Gasket	L-0F260BAA1	
Steel Agent Super	WX0020	Band	L-WX0020001B	Black/Yellow
Steel Agent Super	WX0020	Movement	L-WX0018MV	
Steel Agent Super	WX0020	Back Gasket	L-0F290BAA3	
Steelhead	WX0004	Band	L-WX0004001B	Black/Red
Steelhead	WX0005	Band	L-WX0005001B	Black/Yellow
Steelhead	WX0006	Band	L-WX0006001B	Black/Grey
Steelhead	WX0004	Back Gasket	L-0F286BEA1	
Note: May also come in Model Reference WX0011, WX0013 & WX0014				
Note: Flathead bands DO NOT fit Steelhead watches				
Tempest	WW0002	Back Gasket	L-0F280BAD1	
Note: See also Tempest 3 (WW0007) and Tempest Flow (WW0003) for sub parts				
Tempest 3 (Surf)	WW0007	Band	L-WW0007001B	Translucent Black
Tempest 3 (Surf)	WW0007	Band	L-WW0007401B	Translucent Dark Blue
Tempest 3 (Surf)	WW0007	Band	L-WW0007402B	Translucent Teal Green
Tempest 3 (Surf)	WW0007	Movement	L-WW000320AMV	Silver display
Tempest 3 (Surf)	WW0007	Movement	L-WW000750AMV	Black display (reverse LCD)
Tempest 3 (Surf)	WW0007	Back Gasket	L-0F280BAD1	
Note: See also Tempest (WW0002) and Tempest Flow (WW0003) for sub parts				
Tempest Flow	WW0003	Band	L-WW0003001B	Clear/Black
Tempest Flow	WW0003	Band	L-WW0003404B	Blue
Tempest Flow	WW0003	Band	L-WW0003901B	Dark Blue/Yellow
Tempest Flow	WW0013	Band	L-WW0013401B	Fluoro Green/Yellow
Tempest Flow	WW0003	Movement	L-WW000320AMV	Silver display
Tempest Flow	WW0003	Movement	L-WW000750AMV	Black display (reverse LCD)
Tempest Flow	WW0003	Back Gasket	L-0F280BAD1	
Note: See also Tempest 3 (WW0007) and Tempest (WW0002) for sub parts				
Timber	WK0013	Band	L-WK0013001B	Grey/Black nylon velcro strap
Timber	WK0013	Band	L-WK0013308B	Green/Orange nylon velcro strap
Timber	WK0013	Band	L-WK0013418B	Blue/Black nylon velcro strap
Timber	WK0013	Case	L-WK0013001CA	Black with Black bezel
Timber	WK0013	Case	L-WK0013308CA	Dk Green with Rust bezel
Timber	WK0013	Case	L-WK0013418CA	Blue with Silver bezel
Timber	WK0013	Movement	L-WK0010MV	Silver display
Timber	WK0013	Movement	L-WK0010MVB	Black display (reverse LCD)
Timber	WK0013	Back Gasket	L-WK0009BS	
Triax Analog Regular	WR0019	Band	L-WR0019003B	Black/Silver
Triax Analog Regular	WR0019	Band	L-WR0019201B	Brown/Grey
Triax Analog Regular	WR0019	Band	L-WR0019301B	Light Green
Triax Analog Regular	WR0019	Movement	L-WR0019MV	
Triax Analog Regular	WR0019	Back Gasket	L-0F267BEA1	
Note: See also Triax 26 (WR0001) & Triax 42 (WR0003) for sub bands				
Triax Analog Super	WR0020	Band	L-WR0020003B	Black/Silver
Triax Analog Super	WR0020	Movement	L-WR0020MV	
Triax Analog Super	WR0020	Back Gasket	L-0F349BEA1	
Note: See also Triax 120 (WR0002), Triax 250 (WR0004) & Triax Chronograph (WR0018) for sub bands				

Seiko Australia - Nike Spare Parts Identification Guide (updated 29th June 06)

Model Style Name	Model SKU	Part Description	Part Number	Colour
Triax Armored Chrono Super	WR0068	Movement	L-WR0068MV	
Triax Armored II Chrono	WR0074	Band	L-WR0074001B	Stainless Steel
Triax Armored II Chrono	WR0074	Case	L-WR0074CA	Stainless Steel
Triax Armored II Chrono	WR0074	Movement	L-WR0074MV	
Triax Armored II Chrono	WR0074	Back Gasket	L-WR0074BS	
Triax Armored II Regular	WR0072	Band	L-WR0072001B	Stainless Steel
Triax Armored II Regular	WR0072	Case	L-WR0072CA	Stainless Steel
Triax Armored II Regular	WR0072	Movement	L-WR0072MV	
Triax Armored II Regular	WR0072	Back Gasket	L-WR0072BS	
Triax Blaze	WK0008	Case/Band	L-WK0008001CB	Black with Black bezel
Triax Blaze	WK0008	Case/Band	L-WK0008410CB	Dark Blue with Silver bezel
Triax Blaze	WK0008	Case/Band	L-WK0008429CB	Blue with Silver bezel
Triax Blaze	WK0008	Movement	L-WR0033MV	
Triax Blaze	WK0008	Back Gasket	L-WK0007BS	
Triax Chronograph	WR0018	Band	L-WR0018001B	Black/Silver
Triax Chronograph	WR0018	Band	L-WR0018402B	Blue
Triax Chronograph	WR0018	Case	L-WR0018001CA	Black
Triax Chronograph	WR0018	Movement	L-WR0018MV	
Triax Chronograph	WR0018	Back Gasket	L-0F310BAA1	
Note: See also Triax 120 (WR0002), Triax 250 (WR0004) & Triax Analog Super (WR0020) for sub bands				
Triax Fly	WK0006	Case/Band	L-WK0006001CB	Black with Black bezel
Triax Fly	WK0006	Case/Band	L-WK0006012CB	Black with Red bezel
Triax Fly	WK0006	Case/Band	L-WK0006410CB	Dark Blue with Silver bezel
Triax Fly	WK0006	Case/Band	L-WK0006610CB	Red with Gold bezel
Triax Fly	WK0006	Movement	L-WK0006MVB	Black display (reverse LCD)
Triax Fly	WK0006	Movement	L-WK0006MV	Silver display
Triax Fly	WK0006	Back Gasket	L-WK0006BS	
Triax Junior Analog	WR0033	Band	L-WR0033001B	Grey
Triax Junior Analog	WR0033	Band	L-WR0033002B	Yellow
Triax Junior Analog	WR0033	Band	L-WR0033003B	Translucent black
Triax Junior Analog	WR0033	Band	L-WR0033404B	Translucent Blue
Triax Junior Analog	WR0033	Band	L-WR0033605B	Red
Triax Junior Analog	WR0033	Movement	L-WR0033MV	
Triax Junior Analog	WR0033	Back Gasket	L-WR0033BS	
Note: See also Triax Junior Digital (WR0017) for sub bands & Triax Smooth (WR0070) for sub movement number				
Note: Triax 10 Regular bands can be used for a longer sub				
Triax Junior Digital	WR0017	Band	L-WR0017005B	Black
Triax Junior Digital	WR0017	Band	L-WR0017406B	Blue
Triax Junior Digital	WR0017	Band	L-WR0017410B	Very Dark Blue
Triax Junior Digital	WR0017	Band	L-WR0017411B	Bright Blue
Triax Junior Digital	WR0017	Band	L-WR0017607B	Pink
Triax Junior Digital	WR0017	Movement	L-WR0017MVSML	Old style movement with smaller display
Triax Junior Digital	WR0017	Movement	L-WR0017MV	New style movement with larger display
Triax Junior Digital	WR0017	Back Gasket	L-WR0033BS	
Note: See also Triax Junior Analog (WR0033) for sub bands				
Note: Triax 10 Regular bands can be used for a longer sub				
Triax Metal Linear Regular	WR0039	Band	L-WR0039001B	Stainless Steel
Triax Metal Linear Regular	WR0039	Movement	L-WR003910AMV	
Triax Metal Linear Regular	WR0039	Back Gasket	L-0F296BE11	
Triax Metal Linear Regular	WR0039	Glass	L-WR0039GL	Dark Grey
Triax Metal Linear Regular	WR0039	Glass gasket	L-WR0039GS	
Triax Metal Linear Super	WR0038	Band	L-WR0038001B	Stainless Steel
Triax Metal Linear Super	WR0038	Movement	L-WR003810AMV	
Triax Metal Linear Super	WR0038	Back Gasket	L-0F340BZ11	
Triax Roar	WK0007	Case/Band	L-WK0007001CB	Black with Black bezel
Triax Roar	WK0007	Case/Band	L-WK0007305CB	Light Green with Silver bezel
Triax Roar	WK0007	Case/Band	L-WK0007409CB	Blue with Silver bezel
Triax Roar	WK0007	Case/Band	L-WK0007410CB	Dark Blue with Silver bezel
Triax Roar	WK0007	Case/Band	L-WK0007414CB	Pale Blue with Silver bezel
Triax Roar	WK0007	Case/Band	L-WK0007430CB	Slate Blue with Silver bezel
Triax Roar	WK0007	Case/Band	L-WK0007509CB	Purple with Silver bezel
Triax Roar	WK0007	Case/Band	L-WK0007609CB	Pink with Silver bezel
Triax Roar	WK0007	Case/Band	L-WK0007611CB	Light Purple with Silver bezel
Triax Roar	WK0007	Movement	L-WR0033MV	
Triax Roar	WK0007	Back Gasket	L-WK0007BS	

Seiko Australia - Nike Spare Parts Identification Guide (updated 29th June 06)

Model Style Name	Model SKU	Part Description	Part Number	Colour
Triax Smooth	WR0070	Case/Band	L-WR0070001CB	Black
Triax Smooth	WR0070	Case/Band	L-WR0070002CB	Light Blue
Triax Smooth	WR0070	Case/Band	L-WR0070005CB	Black with gold bezel
Triax Smooth	WR0070	Case/Band	L-WR0070013CB	Sparkly Black with high polish bezel
Triax Smooth	WR0070	Case/Band	L-WR0070018CB	Glossy Black with high polish bezel
Triax Smooth	WR0070	Case/Band	L-WR0070026CB	Black with high polish bezel
Triax Smooth	WR0070	Case/Band	L-WR0070102CB	White with high polish bezel
Triax Smooth	WR0070	Case/Band	L-WR0070212CB	Off White with gold bezel
Triax Smooth	WR0070	Case/Band	L-WR0070407CB	Blue
Triax Smooth	WR0070	Case/Band	L-WR0070413CB	Aqua Blue with high polish bezel
Triax Smooth	WR0070	Case/Band	L-WR0070414CB	Pale Blue with high polish bezel
Triax Smooth	WR0070	Case/Band	L-WR0070501CB	Light Purple with high polish bezel
Triax Smooth	WR0070	Case/Band	L-WR0070506CB	Purple
Triax Smooth	WR0070	Case/Band	L-WR0070602CB	Pink
Triax Smooth	WR0070	Case/Band	L-WR0070606CB	Red
Triax Smooth	WR0070	Case/Band	L-WR0070609CB	Raspberry with high polish bezel
Triax Smooth	WR0070	Case/Band	L-WR0070610CB	Pink with high polish bezel
Triax Smooth	WR0070	Case/Band	L-WR0070706CB	Yellow
Triax Smooth	WR0070	Movement	L-WR0070MV	
Triax Smooth	WR0070	Back Gasket	L-WR0070BS	
Note: See also Triax Junior Analog (WR0033) for sub movement number				
Triax Speed 10 Regular	WR0080	Band	L-WR0080001B	Black
Triax Speed 10 Regular	WR0080	Case	L-WR0080001CA	Black
Triax Speed 10 Regular	WR0080	Movement	L-WR0080MV	
Triax Speed 10 Regular	WR0080	Back Gasket	L-WR0080BS	
Triax Speed 10 Regular	WR0080	Band Pin	L-WR0080PP	
Triax Speed 10 Super	WR0081	Band	L-WR0081001B	Black
Triax Speed 10 Super	WR0081	Case	L-WR0081001CA	Black
Triax Speed 10 Super	WR0081	Movement	L-WR0081MV	
Triax Speed 10 Super	WR0081	Back Gasket	L-WR0081BS	
Triax Speed 10 Super	WR0081	Band Pin	L-WR0081PP	
Triax Speed 50 Regular	WR0082	Band	L-WR0082002B	Black/Yellow
Triax Speed 50 Regular	WR0082	Case	L-WR0082002CA	Black/Grey
Triax Speed 50 Regular	WR0082	Movement	L-WR0082MV	
Triax Speed 50 Regular	WR0082	Back Gasket	L-WR0080BS	
Triax Speed 50 Regular	WR0082	Band Pin	L-WR0080PP	
Triax Speed 50 Super	WR0083	Band	L-WR0083002B	Black/Yellow
Triax Speed 50 Super	WR0083	Case	L-WR0083002CA	Black/Grey
Triax Speed 50 Super	WR0083	Movement	L-WR0083MV	
Triax Speed 50 Super	WR0083	Back Gasket	L-WR0081BS	
Triax Speed 50 Super	WR0083	Band Pin	L-WR0083PP	
Triax Speed 100 Regular	WR0084	Band	L-WR0084001B	Black/Grey
Triax Speed 100 Regular	WR0084	Case	L-WR0084001CA	Black
Triax Speed 100 Regular	WR0084	Movement	L-WR0084MV	
Triax Speed 100 Regular	WR0084	Back Gasket	L-WR0080BS	
Triax Speed 100 Regular	WR0084	Band Pin	L-WR0084PP	
Triax Speed 100 Super	WR0085	Band	L-WR0085001B	Black/Grey
Triax Speed 100 Super	WR0085	Case	L-WR0085001CA	Black
Triax Speed 100 Super	WR0085	Movement	L-WR0085MV	
Triax Speed 100 Super	WR0085	Back Gasket	L-WR0081BS	
Triax Speed 100 Super	WR0085	Band Pin	L-WR0083PP	
Triax Street Regular	WT0006	Band	L-WT0006001B	Stainless steel/Black rubber
Triax Street Regular	WT0006	Case	L-WT0006001CA	Stainless steel (Matt finish)
Triax Street Regular	WT0006	Movement	L-WT0006MV	
Triax Street Regular	WT0006	Back Gasket	L-OF299BZ11	
Triax Street Regular	WT0006	Batt hatch seal	L-WT0006BHS	
Note: See also Triax Strength Regular (WR0063) for sub parts				
Triax Street Super	WT0007	Band	L-WT0007001B	Stainless steel/Black rubber
Triax Street Super	WT0007	Movement	L-WT0007MV	
Triax Street Super	WT0007	Back Gasket	L-WT0007BS	
Triax Street Super	WT0007	Batt hatch seal	L-WT0006BHS	
Triax Strength Regular	WR0063	Band	L-WR0063001B	Black/Grey
Triax Strength Regular	WR0063	Band	L-WR0063302B	Green/Grey
Triax Strength Regular	WR0063	Band	L-WR0063407B	Light Blue/Grey
Triax Strength Regular	WR0063	Case	L-WR0063001CA	Stainless Steel (Shiny finish)
Triax Strength Regular	WR0063	Movement	L-WT0006MV	
Triax Strength Regular	WR0063	Back Gasket	L-OF299BZ11	
Triax Strength Regular	WR0063	Batt hatch seal	L-WT0006BHS	
Note: See also Triax Street Regular (WT0006) for sub parts				
Triax Strength Super	WR0064	Band	L-WR0064001B	Black/Grey - DISCONTINUED
Triax Strength Super	WR0064	Movement	L-WT0007MV	
Triax Strength Super	WR0064	Back Gasket	L-WT0007BS	
Triax Strength Super	WR0064	Batt hatch seal	L-WT0006BHS	

Seiko Australia - Nike Spare Parts Identification Guide (updated 29th June 06)

Model Style Name	Model SKU	Part Description	Part Number	Colour
Triax Sweeper	WK0004	Case/Band	L-WK0004001CB	Grey
Triax Sweeper	WK0004	Case/Band	L-WK0004005CB	Black
Triax Sweeper	WK0004	Case/Band	L-WK0004301CB	Olive Green
Triax Sweeper	WK0004	Case/Band	L-WK0004406CB	Bright Blue
Triax Sweeper	WK0004	Case/Band	L-WK0004501CB	Dark Purple
Triax Sweeper	WK0004	Case/Band	L-WK0004504CB	Light Purple
Triax Sweeper	WK0004	Case/Band	L-WK0004605CB	Red
Triax Sweeper	WK0004	Case/Band	L-WK0004704CB	Yellow
Triax Sweeper	WK0004	Movement	L-WK0004MV	
Triax Sweeper	WK0004	Back Gasket	L-WK0004BS	
Note: Some dial colours available on request.				
Triax Swift 3h	WR0093	Case/Band	L-WR0093002CB	Grey with Silver bezel
Triax Swift 3h	WR0093	Movement	L-WR0093MV	
Triax Swift 3h	WR0093	Back Gasket	L-WX0015BS	
Triax Swift 3i	WR0091	Case/Band	L-WR0091001CB	Black with Black bezel
Triax Swift 3i	WR0091	Case/Band	L-WR0091002CB	Grey with Silver bezel
Triax Swift 3i	WR0091	Case/Band	L-WR0091012CB	Black/Green with Silver bezel
Triax Swift 3i	WR0091	Movement	L-WR0091MV	
Triax Swift 3i	WR0091	Back Gasket	L-WX0015BS	
Triax Swift Analog	WR0078	Case/Band	L-WR0078001CB	Black with Silver bezel
Triax Swift Analog	WR0078	Movement	L-WR0078MV	
Triax Swift Analog	WR0078	Back Gasket	L-WR0078BS	
Triax Swift Digital	WR0090	Case/Band	L-WR0090005CB	Black with Gold bezel
Triax Swift Digital	WR0090	Case/Band	L-WR0090021CB	Black with Black bezel
Triax Swift Digital	WR0090	Case/Band	L-WR0090022CB	Dark Brown with Brown bezel
Triax Swift Digital	WR0090	Case/Band	L-WR0090102CB	White with High Polish bezel
Triax Swift Digital	WR0090	Case/Band	L-WR0090401CB	Dark Blue with Dark Blue bezel
Triax Swift Digital	WR0090	Movement	L-WR0090MV	
Triax Swift Digital	WR0090	Movement	L-WR0090MVB	
Triax Swift Digital	WR0090	Back Gasket	L-WR0090BS	
Triax 10 Regular	WR0006	Band	L-WR0006001B	Black
Triax 10 Regular	WR0006	Band	L-WR0006103B	Translucent Black
Triax 10 Regular	WR0006	Band	L-WR0006106B	White
Triax 10 Regular	WR0006	Band	L-WR0006205B	Translucent Smoky Grey
Triax 10 Regular	WR0006	Band	L-WR0006401B	Translucent Blue
Triax 10 Regular	WR0006	Band	L-WR0006406B	Pale Blue
Triax 10 Regular	WR0006	Band	L-WR0006409B	Bright Blue
Triax 10 Regular	WR0006	Band	L-WR0006410B	Very Dark Blue
Triax 10 Regular	WR0006	Band	L-WR0006504B	Purple
Triax 10 Regular	WR0006	Band	L-WR0006507B	Translucent Purple
Triax 10 Regular	WR0006	Band	L-WR0006603B	Red
Triax 10 Regular	WR0006	Band	L-WR0006604B	Pale Pink
Triax 10 Regular	WR0006	Band	L-WR0006607B	Translucent Bright Red
Triax 10 Regular	WR0006	Band	L-WR0006608B	Shy Pink
Triax 10 Regular	WR0006	Movement	L-WR0006MV	
Triax 10 Regular	WR0006	Back Gasket	L-WR0006BS	
Triax 10 Super	WR0005	Band	L-WR0005001B	Black
Triax 10 Super	WR0005	Band	L-WR0005201B	Translucent Dark Blue
Triax 10 Super	WR0005	Case	L-WR0005001CA	Black
Triax 10 Super	WR0005	Movement	L-WR0005MV	
Triax 10 Super	WR0005	Back Gasket	L-WR0005BS	
Triax 20 Regular	WR0029	Back Gasket	L-0F294BEA1	
Note: See Triax 26 (WR0001), Triax 42 (WR0003) & Triax Analog (WR0019) for sub bands				
Triax 20 Super	WR0030	Back Gasket	L-0F349BEA1	
Note: See Triax 120 (WR0002), Triax 250 (WR0004), Triax Analog Super (WR0020) & Triax Chronograph (WR0018) for sub bands				
Triax 26	WR0001	Band	L-WR0001001B	Black
Triax 26	WR0001	Movement	L-WR0001MV	
Triax 26	WR0001	Back Gasket	L-0F294BEA1	
Note: See also Triax 42 (WR0003) for all sub parts				
Note: See also Triax Analog (WR0019), Triax 20 Regular (WR0029) & Triax 35 Regular (WR0031) for sub bands				
Triax S27 Regular	WR0065	Band	L-WR0065001B	Black
Triax S27 Regular	WR0065	Band	L-WR0065405B	Dark Blue
Triax S27 Regular	WR0065	Band	L-WR0065407B	Light Blue
Triax S27 Regular	WR0065	Band	L-WR0065504B	Purple
Triax S27 Regular	WR0065	Band	L-WR0065706B	Yellow
Triax S27 Regular	WR0065	Case	L-WR0065001CA	Black (Black buttons)
Triax S27 Regular	WR0065	Case	L-WR0065407CA	Black (Grey buttons)
Triax S27 Regular	WR0065	Movement	L-WR0065MV	
Triax S27 Regular	WR0065	Back Gasket	L-WR0065BS	
Triax S27 Regular	WR0065	Batt Hatch Seal	L-WR0065BHS	
Triax S27 Super	WR0066	Band	L-WR0066001B	Black
Triax S27 Super	WR0066	Band	L-WR0066405B	Dark Blue
Triax S27 Super	WR0066	Case	L-WR0066001CA	Black (Black buttons)
Triax S27 Super	WR0066	Movement	L-WR0066MV	
Triax S27 Super	WR0066	Back Gasket	L-WR0066BS	
Triax S27 Super	WR0066	Batt Hatch Seal	L-WR0066BHS	

Seiko Australia - Nike Spare Parts Identification Guide (updated 29th June 06)

Model Style Name	Model SKU	Part Description	Part Number	Colour
Triax 35 Regular	WR0031	Band	L-WR0031001B	Dark Grey/Black
Triax 35 Regular	WR0031	Band	L-WR0031008B	Black/Black
Triax 35 Regular	WR0031/WR003	Back Gasket	L-0F294BEA1	
Note: See Triax 26 (WR0001), Triax 42 (WR0003) & Triax Analog (WR0019) for sub bands				
Triax 35 Super	WR0032/WR003	Back Gasket	L-0F349BEA1	
Note: See Triax 120 (WR0002), Triax 250 (WR0004), Triax Analog Super (WR0020) & Triax Chronograph (WR0018) for sub bands				
Triax 42	WR0003	Band	L-WR0003001B	Black/silver
Triax 42	WR0003	Band	L-WR0003017B	Black/Yellow
Triax 42	WR0003	Band	L-WR0003019B	Grey/Black
Triax 42	WR0003	Band	L-WR0003024B	Blue/Yellow
Triax 42	WR0003	Band	L-WR0003025B	Black/Grey
Triax 42	WR0003	Band	L-WR0003402B	Blue/Clear
Triax 42	WR0003	Band	L-WR0003502B	Translucent Fluoro Pink
Triax 42	WR0003	Case	L-WR0003001CA	Black/silver
Triax 42	WR0003	Movement	L-WR000310AMV	
Triax 42	WR0003	Back Gasket	L-0F294BEA1	
Note: See also Triax 26 (WR0001) for all sub parts				
Note: See also Triax Analog (WR0019), Triax 20 Regular (WR0029) & Triax 35 Regular (WR0031) for sub bands				
Triax 50 Aluminium	WR0008	Case/Band	L-WR0008004CB	Black with Gunmetal bezel
Triax 50 Aluminium	WR0008	Case/Band	L-WR0008010CB	Black with Black bezel
Triax 50 Aluminium	WR0008	Case/Band	L-WR0008011CB	Dark Blue/Silver bezel (blue glass edge)
Triax 50 Aluminium	WR0008	Case/Band	L-WR0008025CB	Black with Silver bezel - DISCONTINUED
Triax 50 Aluminium	WR0008	Case/Band	L-WR0008301CB	Pale Green with Silver bezel
Triax 50 Aluminium	WR0008	Case/Band	L-WR0008402CB	Light Blue with Silver bezel
Triax 50 Aluminium	WR0008	Case/Band	L-WR0008405CB	Dark Blue/Silver bezel (black glass edge)
Triax 50 Aluminium	WR0027	Case/Band	L-WR0027001CB	Light Grey with Silver bezel (Ltd Edit.)
Triax 50 Aluminium	WR0008	Movement	L-WR000810AMV	
Triax 50 Aluminium	WR0008	Back Gasket	L-0F294BEA1	
Note: See also Triax 42 (WR0003) & Triax 26 (WR0001) for sub movement				
Note: May also come in Model Reference WR0027, WR0053 & WR0054				
Triax 120	WR0002	Band	L-WR0002005B	Red
Triax 120	WR0002	Band	L-WR0002009B	Black
Triax 120	WR0002	Band	L-WR0002010B	Dark Grey
Triax 120	WR0002	Movement	L-WR0002MV	
Triax 120	WR0002	Back Gasket	L-0F349BEA1	
Note: See also Triax 250 (WR0004) for all sub parts				
Note: See also Triax Analog Super (WR0020) & Triax Chronograph (WR0018) for sub bands				
Triax 250	WR0004	Band	L-WR0004001B	Black/Gold
Triax 250	WR0004	Band	L-WR0004016B	Dark Grey/Silver
Triax 250	WR0020	Band	L-WR0020003B	Black/Silver
Triax 250	WR0004	Movement	L-WR0004MV	Silver display
Triax 250	WR0004	Movement	L-WR0004MVB	Black display (reverse LCD)
Triax 250	WR0004	Back Gasket	L-0F349BEA1	
Note: See also Triax 120 (WR0002) for all sub parts				
Note: See also Triax Analog Super (WR0020) & Triax Chronograph (WR0018) for sub bands				
Triax 300 Aluminium	WR0007	Case/Band	L-WR0007405CB	Dark Blue with Gunmetal bezel - DISCONTINUED
Triax 300 Aluminium	WR0007	Movement	L-WR000710AMV	Silver display
Triax 300 Aluminium	WR0007	Movement	L-WR0007MVB	Black display (reverse LCD) - DISCONTINUED
Triax 300 Aluminium	WR0007	Back Gasket	L-0F349BEA1	
PLEASE NOTE: All other colour case/bands for Triax 300 Aluminium are now discontinued & no longer available				
Note: See also Triax 250 (WR0004) & Triax 120 (WR0002) for sub movement				
Note: May also come in Model Reference WR0028, WR0040 & WR0058				
Typhoon	WW0001	Case/Band	L-WW0001001CB	Black with silver bezel
Typhoon	WW0001	Case/Band	L-WW0001003CB	Translucent dark green with silver bezel
Typhoon	WW0001	Case/Band	L-WW0001403CB	Translucent blue with silver bezel
Typhoon	WW0001	Case/Band	L-WW0001601CB	Translucent red with silver bezel
Typhoon	WW0001	Movement	L-WW0001MV	
Typhoon	WW0001	Back Gasket	L-WW0001BS	
Typhoon World	WW0009	Band	L-WW0009001B	Black
Typhoon World	WW0009	Band	L-WW0009401B	Blue
Typhoon World	WW0009	Movement	L-WW000910AMV	
Typhoon World	WW0009	Back Gasket	L-0F315BZA1	
Unholey Ron Digital	WC0012	Band	L-WC0012001B	Black metal
Unholey Ron Digital	WC0012	Movement/Case	L-WC0012001MV	Black (complete watch head)
Unholey Ron Digital	WC0012	Push pin	L-WC0002PP	
Unholey Ron Digital	WC0012	Batt hatch seal	L-WC0001BHS	
Note: This is a complete list of Seiko Australia's current inventory of Nike spare parts. It is designed as an aid for identifying part numbers by the Style Name and Model SKU - with the inclusion of a basic description of band & case primary colours. This list will be updated as parts for new models are introduced.				
For any queries, prices & availability please contact Seiko Spare Parts Dept.				